


# HOME DECORATORS COLLECTION

BF-25186 OXFORD TIER SHOE CABINET 3 TIER

INV#19116













ASSEMBLY INSTRUCTIONS

Made In China



















Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have came loose inside the carton during shipment. Count all parts and material hardware, then compare with parts list to be sure all parts are present. If any parts are missing or damaged, phone, fax, or mail to our Customer Service Department for efficient and speedy service. Please indicate the model number and code letter of part(s) needed.

**IMPORTANT NOTE:** Follow instructions listed below in proper sequence as numbered to assure fast, easy and correct assembly.



PARTS LIST		
<b>A</b>  TOP PANEL-1PC	<b>B</b>  LEFT SIDE PANEL-1PC	<b>C</b>  RIGHT SIDE PANEL-1PC
<b>D</b>  BOTTOM PANEL-1PC	<b>E</b>  ADORNING PANEL-1PC	<b>F</b>  UP BACK PANEL-1PC
<b>G</b>  DOWN BACK PANEL-1PC	<b>H</b>  ACROSS PANELS-2PCS	<b>I</b>  DRAWER PANEL FRONTS-3PCS
<b>J</b>  LEFT DRAWER PANEL SIDES-3PCS	<b>K</b>  RIGHT DRAWER PANEL SIDES-3PCS	<b>L</b>  DRAWER PANEL BACKS-3PCS

**NOTE:** THE SURFACE WITH THE STICKER IS THE BACK SIDE.

<b>M</b>  DRAWER PANEL STANDS-3PCS	<b>N</b>  DRAWER PANEL BOTTOMS-3PCS	<b>O</b>  DRAWER SUPPORT PANELS-3PCS
<b>P</b>  CAM-TOOL-1PC	<b>Q</b>  CAM-BOLTS-30PCS	<b>R</b>  CAM-LOCKS-30PCS
<b>S</b>  DOWELS-12PCS	<b>T</b>  KNOBS-6PCS	<b>U</b> 8mm × 5/8"  SCREWS-6PCS
<b>V</b> 6mm × 1"  SCREWS-48PCS	<b>W</b>  HINGES-6PCS	<b>X</b>  HOOKS-4PCS
<b>Y</b>  PLASTIC BELTS-2PCS	<b>Z</b>  GECKOS-4PCS	<b>A1</b> 6mm × 3/4"  SCREWS-4PCS
<b>B1</b> 7mm × 7/8"  SCREWS-4PCS		




NOTE: THE SURFACE WITH THE STICKER IS THE BACK SIDE.

NOTE: • UPON OPENING, THOROUGHLY CLEAN ALL WOOD SURFACES TO REMOVE DUST AND DIRT THAT MAY HAVE SETTLED ONTO FINISH DURING SHIPMENT. IN ORDER TO PREVENT DAMAGE DURING ASSEMBLY, PLEASE ASSEMBLE THIS ITEM WITH AT LEAST TWO PEOPLE.




NOTE: TURN THE CAM-BOLT SCREWS UNTIL THEY ARE TIGHT, THE SHOULDER SHOULD BE AGAINST THE SURFACE OF THE PART.

## HOW TO USE THE CAM-TOOL




NOTE: • THE ARROWS ON THE HIDDEN CAM-LOCKS SHOULD POINT TO THE CAM-BOLTS




1). ASSEMBLE THE DOWN BACK PANEL (G).

- ROTATE 3 CAM-BOLTS (Q) INTO THE HOLES IN THE BOTTOM PANEL (D).
- PLACE THE CAM-BOLTS (Q) INTO THE HOLES IN THE DOWN BACK PANEL (G) AND ATTACH USING 3 CAM-LOCKS (R).




2). ASSEMBLE THE ADORNING PANEL (E).

- ROTATE 3 CAM-BOLTS (Q) INTO THE HOLES IN THE ADORNING PANEL (E).
- PLACE THE CAM-BOLTS (Q) INTO THE HOLES IN THE BOTTOM PANEL (D) AND ATTACH USING 3 CAM-LOCKS (R).




3). ASSEMBLE THE LEFT SIDE PANEL (B).

- ROTATE 9 CAM-BOLTS(Q) AND INSERT 3 DOWELS(S) INTO THE HOLES IN THE LEFT SIDE PANEL (B).
- PLACE THE CAM-BOLTS(Q) INTO THE HOLES IN THE PANEL (D/F/H/G) AND ATTACH USING 9 CAM-LOCKS (R).




4). ASSEMBLE THE RIGHT SIDE PANEL (C).

- ROTATE 9 CAM-BOLTS(Q) AND INSERT 3 DOWELS(S) INTO THE HOLES IN THE RIGHT SIDE PANEL (C).
- PLACE THE CAM-BOLTS(Q) INTO THE HOLES IN THE PANEL (D/H/F/G) AND ATTACH USING 9 CAM-LOCKS (R).



5). ASSEMBLE THE TOP PANEL(A).


- ROTATE 6 CAM-BOLTS(Q) INTO THE HOLES IN THE TOP PANEL(A).
- PLACE THE CAM-BOLTS(Q) INTO THE HOLES IN THE PANEL(B/C/F) AND ATTACH USING 6 CAM-LOCKS(R).



#### 6). ASSEMBLE THE DRAWER.


- ATTACH DRAWER PANEL SIDE(J/K) TO DRAWER PANEL FRONT(I) USING 4 SCREWS(V).
- ATTACH THE KNOBS(T) TO DRAWER PANEL FRONT(I) USING 2 SCREWS(U).
- INSERT THE DRAWER PANEL BOTTOM(N) INTO THE SLOTS IN THE DRAWER PANEL SIDE(J/K).
- ATTACH THE DRAWER PANEL BACK(L) BETWEEN LEFT DRAWER PANEL SIDE(J) AND RINGTH DRAWER PANEL SIDE(K) USING 4 SCREWS(V).
- ATTACH THE DRAWER PANEL STAND(M) TO DRAWER PANEL SIDE(J/K) USING 4 SCREWS(V).





7). ASSEMBLE THE DRAWER SUPPORT PANEL (O).

- ATTACH THE DRAWER SUPPORT PANEL (O) TO DRAWER PANEL BOTTOM (N) USING 4 SCREWS (V).




8). ASSEMBLE THE DRAWER.

- INSERT 2 HINGES (W) INTO THE HOLES IN THE DRAWER PANEL FRONT (I).
- PLACE THE HINGES (W) INTO THE HOLES IN THE SIDE PANEL (B/C).



# Warning

The anti-tip hardware must be used as part of assembly!



9). ASSEMBLE THE DRAWER AND HOOKS (Z).

- INSERT 6 DOWELS(S) INTO THE HOLES IN THE DRAWER PANEL SIDE(J/K).
- ATTACH 2 HOOKS(X) TO TOP PANEL(A) USING 4 SCREWS(A1).



#### 10). ASSEMBLE THE ANTI-TIP HARDWARE.

- DRILL 4 HOLES INTO THE WALL, PLEASE REFER TO THE REAR TOP PANEL'S HOLE DISTANCE AND HEIGHT.
- PUT 4 GECKOS(Z) INTO THE HOLES IN THE WALL, AND ROTATE 4 SCREWS(B1) INTO THE GECKOS(Z).
- CONNECT THE TWO HOOKS(X) WITH A PLASTIC BELT(Y).